Interleaved 2 of 5 (I 2 of 5)

The following options apply to the I 2 of 5 symbology.

12 of 5 Enable/Disable

When disabled, the reader will not read I 2 of 5 bar codes.









Product Reference Guide 201

Interleaved 2 of 5 (I 2 of 5) — cont.


I 2 of 5 Check Character Calculation — cont.





I 2 of 5 Check Character Transmission

Enable this option to transmit the check character along with I 2 of 5 bar code data.









Product Reference Guide 203

Plessey

The following options apply to the Plessey symbology.

Plessey Enable/Disable

Enables/Disables ability of reader to decode Plessey labels.









Plessey — cont.

Plessey Check Character Calculation

Enables/Disables calculation and verification of an optional Plessey check character.











Plessey Check Character Calculation = Enable Anker check char. verification



Plessey Check Character Calculation =
Enable Plessey std. and Anker check char verification

Product Reference Guide 297

Plessey — cont.

Plessey Check Character Transmission

Enables/disables transmission of an MSI check character.









PLessey Length Control

This feature specifies either variable length decoding or fixed length decoding for the Plessey symbology.

Variable Length — For variable length decoding, a minimum and maximum length may be set.

Fixed Length — For fixed length decoding, two different lengths may be set.









QuickScan[™] QD2100